

EUROVENT
CERTIFIED PERFORMANCE



INSTRUCTIONS FOR INSTALLATION, USE AND MAINTENANCE

VTP/ VTS/ VTI

CA' D'ORO fan coil heaters



TONONFORTY 
the perfect climate

CE

INDEX_TABLE

1.0 FEATURES OF THE HEATER	p. 8
1.1 DESCRIPTION OF THE HEATER	p. 8
1.2 DESCRIPTION OF THE COMPONENTS	p. 8
1.3 AVAILABLE TYPES	p. 8
2.0 INSTRUCTIONS FOR CORRECT INSTALLATION	p. 8
2.1 PACKAGING AND TRANSPORT	p. 8
2.2 INSTALLING THE VARIOUS MODELS	p. 8
3.0 HYDRAULIC CONNECTIONS	p. 9
4.0 ELECTRIC CONNECTIONS	p. 9
5.0 INVERTING THE BATTERY ATTACHMENTS	p. 10
1.0 START VP	p. 29
2.0 REGULATION ACCESSORIES	p. 29
3.0 USING THE FAN-COIL HEATER	p. 29
4.0 MAINTENANCE	p. 29
5.0 FAULT FINDING	p. 29

ATTENTION:

Every intervention must be done by qualified staff and following the safety norms in force. Before every intervention on the fan coils, please, read carefully this manual. The present manual must be kept for all the machine life for future information. Tonon Forty Spa declines every responsibility for any installation or for using not listed into this manual.

1.0 FEATURES OF THE HEATER**1.1 DESCRIPTION OF THE HEATER**

The "CA' D'ORO" fan coil heater is a terminal unit for room air conditioning, ventilation, heating in the winter and cooling in the summer.

1.2 DESCRIPTION OF THE COMPONENTS

BEARING STRUCTURE: made from adequately thick galvanised steel plate, sound and heat insulated.

HEAT EXCHANGE BATTERY: made with copper tubes mechanically expanded into aluminium fins, 1/2" F bronze manifolds for water attachments with air valve (maximum working pressure 10 bar).

FAN UNIT: double intake centrifugal fans with 1-2-3 fan wheels, single phase three-speed electric motor with heat protection and condenser permanently activated.

FILTER UNIT: made from a micro-perforated propylene panel fitted on a hearing frame with a protection grid, fitted to the intake side, it can be easily removed for cleaning or washing.

COVER: made from moulded and painted steel plate, resistant to chemical agents and insulated with anti-condensation material, the delivery grid directions can be changed and the access flaps to the electric and hydraulic controls are made in heat resistant ABS. Colours are RAL 9010 series, with other colours available on request.

1.3 AVAILABLE TYPES

The following types are available:

VTP = wall fitted version

VTS = ceiling fitted version

VTI = built-in version for the wall or ceiling

All the fan coil heaters have a central thermostat fitted standard (the motor turns only if the water in the exchanger has reached a temperature of 35°C).

2.0 INSTRUCTIONS FOR CORRECT INSTALLATION**2.1 PACKAGING AND TRANSPORT**

Each single unit is packed in a strong cardboard box protected by polythene and polystyrene shock buffers.

The unit must be handled with care during transport and movement. No more than three units must be stored on top of each other in the vertical position and no more than five in a horizontal position. Check the packaging is not damaged and do not use any sharp or cutting instruments to open it. When the unit has been removed from the box, check that it is not damaged and corresponds to the model effectively ordered with the relative accessories. Any sort of problem should be immediately communicated to the constructor.

2.2 INSTALLING THE VARIOUS MODELS

Installation must be done by a qualified technician, before beginning check that the power supply corresponds to the requirements printed on the plaque attached to each single unit, which also gives the serial and model number. If the unit is supplied with feet, these should be fitted internally and externally and the supplementary tray if supplied (VEV - VEO). Drill the wall for the VTP and VTP/ZC models, drill the ceiling for the VTS and VTS/ZC models, following the measurements given in the "dimensions" page. Mount the fan coil heater using the expansion nuts and through screws in the slots on the edge of the unit, the screws must have a minimum diameter of 6 mm with a washer under the screw head. The same procedures are used for fixing the VTI and VTI/F models to the wall or ceiling. The air conditioning ceiling versions mounted on the

ceiling must be installed with special attention paid to the inclination, to ensure the condensation water is emptied into the horizontal tray, the outlet pipe must be a 16 mm diameter flexible tube and smooth inside. If the unit is installed in the bathroom, it must be placed in a position where the switches and controls cannot be touched by anyone in the bath or shower. The power lead must have a normal PVC sheath (designation 227 EIC 53) type N07V-K or FROR, measuring 3x1.5 mm (for versions with heating element, use a lead with the section adequate to the power intake). The heater must not be placed beneath a power socket.


WARNING!

FOR THE BUILT-IN VERSIONS, THE TEMPLATE IS PREPARED ON SITE, AND THE DIMENSIONS OF THE AIR INTAKE AND DELIVERY SECTIONS MUST BE RESPECTED AND ATTENTION MUST BE PAID THAT THERE IS NO CONTACT BETWEEN THE MOVING PARTS AND THE POWERED ELECTRIC PARTS.


For the ceiling mounted versions, it is advisable not to mount the fan-coil heater at more than 2.5-2.8 meters from the floor, to avoid air recycling during the heating phase.

VTP-VTS MODELS


Remove the cover (1), by unscrewing the two screws (2) on the bottom edge and lift it in the direction shown by the arrows, to completely extract it from the positioning pins (3). During these operations it is advisable to replace the unit and filter in its packaging.




2.3 CONFIGURATIONS




VTP
VERTICAL WALL VERSION




VTS
HORIZONTAL CEILING VERSION




VTI
VERTICAL BUILT-IN VERSION



VTI
HORIZONTAL BUILT-IN VERSION



VTI/F
VERTICAL BUILT-IN VERSION WITH FRONTINTAKE



VTI/F
HORIZONTAL BUILT-IN VERSION WITH FRONTINTAKE

3.0 HYDRAULIC CONNECTIONS

Connect the heat exchanger using a 1/2" GF attachment to the water supply, using a spanner and counter-spanner to avoid damage to the battery connections. The pipes can come from the floor, wall or ceiling. To bleed any air in the circuit, use a flat screwdriver to open the valve on the top at the side of the attachments. If the fan-coil heater is also used for air conditioning, connect the condensation outlet to the collection circuit; if the additional external tray has not been requested, the cooling water pipes must be insulated against condensation. It is advisable to make a water trap on the condensation outlet pipe to avoid intake of evil-smelling air. When the connections are terminated, check there are no water leaks from the exchanger or tray. The exchangers are supplied to work with a maximum pressure of 10 bar. The battery attachments on the standard unit are on the left but if needed they can be moved to the right (refer to the inverting battery attachments chapter). To install the valves on the two or four pipe versions, follow the instructions given in the technical manual or included in the valve kit.

- IN COOLING FUNCTION (TO AVOID WATER CONDENSING) WE SUGGEST EV2, EV4.

4.0 ELECTRIC CONNECTIONS

Turn the power off at the mains before beginning the electric connections. The connections must be made in conformity with current standards in force following the enclosed wiring diagram with each fan-coil heater. All the fan-coil heaters are supplied with a connection box (standard fitting on the right), which contains all the regulation components and the grounding terminal. To reach the components, unscrew the two screws in the cover next to the lead outlets. Each fan-coil heater must be powered with single phase 230 volts (tolerance of -5/+10) 50 Hz frequency. A bipolar motor-circuit switch must be installed upstream from the fan-coil heater.

THE CONNECTION BOX CONTAINS:

Standard wall mounted models with cover**VTP/VB version**

- VB controls complete with summer/winter - off selection switch and 3 speed selection switch.
- Consent thermostat (for heating)
- Power terminal board

VTP/AB version

- AB control complete with summer/winter - off selection switch, 3 speed selection switch and room temperature regulation thermostat.
- Consent thermostat (for heating).
- Power terminal board

VTP/CRE version

- Onboard electronic control
- OFF, E/I and 3 fan speeds
- Automatic/manual speed modes
- Ambient temperature thermostat
- Valve control
- Fan consent sensor

Standard models without cover or ceiling mounted (VTI/VTS)

The box just contains a terminal board for connecting the motor (simple or three speed), the consent thermostat and the grounding terminal. All the settings for speed, temperature, etc, are done by the installer. On request TONON S.p.A., can supply the following controls which can be mounted on the wall: **CVM**: three speed regulator and summer/winter selection switch. **TAM**: electronic thermostat and summer/winter selection switch. **CEM**: three speed regulator, summer/winter selection switch and solenoid valve control. **CEM/D**: electronic thermostat, three speed regulator, summer/winter heating element and solenoid valve control selection switch. **CRE**: Electronic thermostat with manual and automatic speed switch, manual and automatic summer/winter switch, valve control and electric heating element. These controls are mounted on the wall using screws and expansion nogs as described in the instructions contained with the controls. If the heating element is installed, it must be powered separately paying special attention to the absorbed current (refer to the technical feature plaque on the heater). The heater must always be grounded.

electronic thermostat, summer/winter selection switch and solenoid valve control **CEM/D**: electronic thermostat, three speed regulator, summer/winter heating element and solenoid valve control selection switch. **CRE**: Electronic thermostat with manual and automatic speed switch, manual and automatic summer/winter switch, valve control and electric heating element. These controls are mounted on the wall using screws and expansion nogs as described in the instructions contained with the controls. If the heating element is installed, it must be powered separately paying special attention to the absorbed current (refer to the technical feature plaque on the heater). The heater must always be grounded.

5.0 INVERTING THE BATTERY ATTACHMENTS

A Dismantle the electric control panel.

B Disconnect the motor lead connector - **POS. 9**.

C Dismantle the consent thermostat **POS. 4** pulling it out from the battery fins.


D Loosen the motor base fixing screws **POS. 10**, remove the battery fixing screws **POS. 6**; hold the battery at both ends and pull it out in the direction of the arrow (taking care not to damage the insulation), rotate the battery by 180°, replace the attachments on the opposite side and tighten the screws **POS. 10**.

E Invert the position of the condensation outlet plug **POS. 7** and the position of the condensation tray **POS. 8**, if fitted.


F Dismantle the motor connection lead from the right side and fit it to the housing on the left side.

G Reassemble the electric control panel on the opposite side, connect the electric leads (follow the wiring diagram).


H Place the consent thermostat (or probe) between the battery fins, in the opposite position from before; if the room air thermostat is fitted, position the bulb (or probe) with the special fixings **POS. 3**.

5.0 - INVERTING THE BATTERY ATTACHMENTS

**VTP / AB
VTP / CRE**





VTP / VB





DATI DIMENSIONALI, MEASUREMENTS, BESCHAFFENHEIT UND AUSSENMABE, DONNEES CONCERNANT LES DIMENSIONS,
DIMENSIONES

VTS





VTP





ATTACCHI 1/2"
ATTACHMENTS 1/2" F
ANSCHLUSS 1/2" F
ATTACHES 1/2" F
CONEXIONES 1/2" F

VTS/ZC



VTS/ZC




ATTACCHI 1/2"
ATTACHMENTS 1/2" F
ANSCHLUSS 1/2" F
ATTACHES 1/2" F
CONEXIONES 1/2" F

MODELLO - MODEL - MUSTER - MODÉLE - MODELO	10	20	30	40	50-60	70-80
Dimensioni d'ingombro, Overall Size, Befestigungslocher, Dimemiom d'enconibrement, Dimensiones						
A	660	810	960	1100	1410	1710
B	220	220	220	220	230	230
C	480	480	480	480	525	525
Fori di fissaggio, Fijing holes, AussenmaBe, Trou de mecordement mur, Agujeros de sujecion						
D	415	565	715	865	1165	1465
E	200	200	200	200	225	225
F	70	70	70	70	95	95
Attacchi standard, Standard attachments, Standardanschliisseanschluss, attaches standard, Conexiones estandares						
G	42	42	42	42	42	42
H	130	130	130	130	155	155
I	238	238	238	238	249	249
L	389	389	389	389	444	444
Attacchi batteria supplementare, Additional battery attachments, Zusatzbatterieabfluss, Attaches batt. suppl, Conexiones bat. sup						
M	112	112	112	112	112	112
N	149	149	149	149	174	174
O	307	307	307	307	318	318
P	372	372	372	372	427	427
Scarico condensa, Condensation outlet, Kondenswasser, Deciargement condensation, Descarga condensado						
Q	96	96	96	96	100	100
231	231	231	231	231	243	243
S	202	202	202	202	212	212
Distanza, Dist., Abst., Dist., Dist.						
	120	120	120	120	130	130


DATI DIMENSIONALI, MEASUREMENTS, BESCHAFFENHEIT UND AUSSENMABE, DONNEES CONCERNANT LES DIMENSIONS,
DIMENSIONES

VTI




ATTACCHI 1/2"
ATTACHMENTS 1/2" F
ANSCHLUSS 1/2" F
ATTACHES 1/2" F
CONEXIONES 1/2" F

VTI/F




ATTACCHI 1/2"
ATTACHMENTS 1/2" F
ANSCHLUSS 1/2" F
ATTACHES 1/2" F
CONEXIONES 1/2" F

MODELLO - MODEL - MUSTER - MODÈLE - MODELO	10	20	30	40	50-60	70-80
Dimensioni d'ingombro, Overall Size, Befestigungslocher, Dimemiom d'enconibrement, Dimensiones						
A	562	712	862	1012	1312	1612
B	216	216	216	216	226	226
C	445	445	445	445	490	490
Fori di fissaggio, Fijing holes, AussenmaBe, Trou de mecordement mur, Agujeros de sujecion						
D	415	565	715	865	1165	1465
E	200	200	200	200	225	225
F	70	70	70	70	95	95
Attacchi standard, Standard attachments, Standardanschliisseanschluss, attaches standard, Conexiones estandares						
G	42	42	42	42	42	42
H	130	130	130	130	155	155
I	238	238	238	238	249	249
L	389	389	389	389	444	444
Attacchi batteria supplementare, Additional battery attachments, Zusatzbatterieabfluss, Attaches batt. suppl, Conexiones bat. sup						
M	112	112	112	112	112	112
N	149	149	149	149	174	174
O	307	307	307	307	318	318
P	372	372	372	372	427	427
Scarico condensa, Condensation outlet, Kondenswasser, Deciargement condensation, Descarga condensado						
Q	96	96	96	96	100	100
231	231	231	231	231	243	243
S	202	202	202	202	212	212



MOD. VTP/AB



230V 50 Hz

Allacciamento elettrico Mod. VTP/VB - VTP/AB

- 1 cavo d'alimentazione (min.3x1.5 mmq)
- 2 SCHEMA ELETTRICO VTP/VB
- 3 SCHEMA ELETTRICO VTP/AB
- 4 Sonda ambiente
- 5 Valv. per 2 tubi
- EV 1 = ELETTROVALVOLA
"RAFFREDDAMENTO"
- EV 2 = ELETTROVALVOLA
"RISCALDAMENTO"

Electric wiring types VTP/VB-VTP/AB

- 1 supply lead (min. 3x1.5 mm2)
- 2 WIRING DIAGRAM VTP/VB
- 3 WIRING DIAGRAM VTP/AB
- 4 Roomprobe
- 5 Valve for 2 pipes
- EVI = "COOLING" SOLENOID
- EV2 = "HEATING" SOLENOID

Elektrische Anschlüsse Mod. VTP/VB - VTP/AB

- 1 Stromkabel (min. 3 x 1.5 mm2)
- 2 SCHALTPLAN VTP/VB
- 3 SCHALTPLAN VTP/AB
- 4 Raumsondc
- 5 Vendi fir 2 rohre
- EV1=ELEKTROVENTIL "KUHLUNG"
- EV2=ELEKTROVENTIL "HEIZUNG"


Branchemet électrique Mod. VTP/VB-VTP/AB

- 1 Cable d'alimentation (min. 3 x 1.5 mm2)
- 2 SCHEMA ÉLECTRIQUE VTP/VB
- 3 SCHEMA ÉLECTRIQUE VTP/AB
- 4 Sonde environnement
- 5 Soupape pour 2 tubes
- EVI = ELECTROVALVULA
"REFROIDISSEMENT"
- EV2 = ELE CTROVANNE
"CHAUFFAGE "

Conexión eléctrica Mod. VTP/VB - VTP-P/AB


- 1 Camble de alimentación (min.3x1.5)
- 2 ESQUEMA ELECTRICO VTP/VB
- 3 ESQUEMA ELECTRICO VTP/AB
- 4 Sonda ambiente
- 5 Valv. para 2 tubos
- EV 1 = ELECTROVALVULA
"REFRIGERACION"
- EV 2 = ELECTROVALVULA
"CALEFACCION"

(2) MOD. VTP/VB



230V 50 Hz TDC

FUNZIONAMENTO IN CONDIZIONAMENTO
CONDITIONING



KÜHLEN

FONCTIONNEMENT EN CONDITIONNEMENT

FUNCIONAMIENTO EN LA FASE DE

ACONDICIONAMIENTO


FUNZIONAMENTO IN RISCALDAMENTO
HEATING



HEEEN

FONCTIONNEMENT EN CHAUFFAGE

FUNCIONAMIENTO EN LA FASE DECALEFACCÓN



Allacciamento elettrico 230V 50Hz

1 cavo d'alimentazione (min. 3 x 1.5 mmq)

Electric wiring types 230V 50Hz

1 supply lead (min. 3 x 1.5 mm²)

Elektrische Anschlüsse 230V 50Hz



1 Stromkabel (min. 3 x 1.5 mm²)

Branchemiento eléctrico 230V 50Hz


1 Cable d' alimentation (min. 3 x 1.5 mm¹)

Conexión eléctrica 230V 50Hz

1 Cable de alimentación (min. 3 x 1.5 mm²)



CVM + TDC
MOD VTS 10 - 80
MOD VTI 10 - 80



TAM + TDC
MOD VTS 10 - 80
MOD VTI 10 - 80


Collegamento effettuato alla velocità media

Wired for medium speed


Bei mittlerer Geschwindigkeit durchgeföhrte Verbindung

Branchemiento effectué à vitesse moyenne

Conexión efectuada a la media velocidad




C3V + TAA + TDC + DEI + RES
MOD VTP 10-30




C3V + TAA + TDC + DEI + RES
MOD VTP 40-80


SCHEMI ELETTRICI, WIRING DIAGRAMS, SCHALTPPLANE, SCHEMAS ELECTRIQUES, ESQUEMAS ELECTRICOS




**TDC + RES + EV
MOD. VTS 10 - 80
MOD. VTI 10 - 80**




**CEM + EV + TDC
MOD. VTS 10 - 80
MOD. VTI 10 - 80**




**CEM+TDC+EV1+EV2
MOD. VTS 10 - 80
MOD. VTI 10 - 80**



**CEM/D+TDC
MOD. VTS 10 - 80
MOD. VTI 10 - 80**



**CEM+TDC+EV1
MOD. VTS 10 - 80
MOD. VTI 10 - 80**





**CEM/D+TDC+EV1+EV2
MOD. VTS 10 - 80
MOD. VTI 10 - 80**

Parametri manuale, Parameters of the manual, Parameter des Handbuchs,
Parametres manuel, Parámetros del manual CEM/D:
P02= Selezionare, select, auswählen, sélectionner, seleccionar
P07= 2

Parametri manuale, Parameters of the manual, Parameter des Handbuchs,
Parametres manuel, Parámetros del manual CEM/D:
P01= 1
P02= Selezionare, select, auswählen, sélectionner, seleccionar
P07= 2

SCHEMI ELETTRICI, WIRING DIAGRAMS, SCHALTPPPLANE, SCHEMAS ELECTRIQUES, ESQUEMAS ELECTRICOS

CDM/D



CEM/D+TDC+EV1+RES
MOD. VTS 10 - 80
MOD. VTI 10 - 80

Verificare i parametri, Verify the parameters, Kontrollieren die Parameter, Verifier les paramètres, Comprobar los parámetros:

PO1= 2

PO2= Selezionare, select, auswählen, sélectionner, seleccionar

PO7= 2

P21= 60

FUNZIONAMENTO IN CONDIZIONAMENTO
CONDITIONING

KÜHLEN

FONCTIONNEMENT

EN CONDITIONNEMENT

FUNCIONAMIENTO EN LA FASE DE

ACONDICIONAMIENTO

FUNZIONAMENTO IN RISCALDAMENTO

HEATING

HEEEN


FONCTIONNEMENT

EN CHAUFFAGE


FUNCIONAMIENTO EN LA

FASE DECALEFACCIÓN


CRE



CRE




CRE




230V 50Hz

CRE+H2O+EV
MOD. VTS/I 10-80

CRE



CRE



230V 50Hz

CRE+H2O+EV1+EV2
MOD. VTS/I 10-80

C3V= commutatore 3 velocità TDC= termostato di consenso TAA= termostato aria ambiente DEI= deviatore estate - inverno TAM= termostato amb. a muro CVM= commutatore a vel. a muro CEM= Comando remoto Estate/Inverno - Termostato ambiente - Commutatore tre velocità - Comando valvole CEM/D= Estate/Inverno commutatore manuale e automatica - Termostato ambiente - Comando valvole - Commutatore tre velocità manuale e automatica DTSR= doppio termostato di sicurezza resistenza elettrica RES= resistenza elettrica IRE= interruttore res. elettrica REL= relé resistenza per mod. 40 - 80 EV1= elettrovalvola "raffreddamento" EV2= elettrovalvola "riscaldamento" L= linea N= neutro ±= terra e= condizionamento c= bianco (comune motore) I= rosso (min) II= blu (med) III= nero e= giallo - verde (terra) f= alimentazione ---= limite cablaggio interno	C3V= 3 speed selection switch TDC= coment thermostat TAA= room air thermostat DEI= summer-winter selection switch TAM= wallfitted room thermostat CVM= wallfitted 3 speed selection switch CEM= model remote control Summer/Winter - Room thermostat - Three-speed switch - Valve controls CEM/D= Comando Res. Elettrica o manual and auto Summer/Winter switching - Room thermostat - Valve control - manual and auto three-speed switch - Heating element Controls DTSR= doublé thermostat far heating element safety RES= heating element IRE= heating element switch REL= heating element relayfar types 40-80 EVI= "cooling" solenoidi EV2= "heating" solenoid L= power line N= neutra! ±= earth e= cooling e= white (common motor) I= red (min.) II= blue(med) III= biade (max.) e= yellow-green (earth) f= power ---= limitfor internai wiringù	C3V= 3 Geschwindigkeitsiten-regler TDC= Zustimmungsthermostat TAA= Raumluftthermostat DEI= Umleiter Sommer- Winter TAM= Raumthermostat Wandmontiert CVM= 3 Geschwindigkeitenregler Wandmontiert Raumregler Mod. CEM . Sommer/Winter - Raumthermostat - 3-Stufen-Wahlschalter - Ventilsteuerung. Raumregler Mod. CEM-D. Sommer/Winter manuelle und automatische Umschaltung - Raumthermostat - Ventilsteuerung - manueller und automatischer 3-Stufen-Wahlschalter - Steuerung elektr. Widerstand. RES = elektrischer Widerstand IRE = Schalter elektrischer Widerstand REL= Widerstandsrelais far Mod. 40-80 EVI= Elektroventil "Kühlung" EV2= Elektroventil "Heizung" L= Linie N= Neutral ±= Erde e= Klimatisierung e= weiB (einfacher Motor) I= rat (min) II= blau (med) FU= schwarz (max) e= gelb-grün (Erde) f= Stromversorgung --- = Grenze innere Verkablung	C3V= commutateur 3 vitesses TDC= thermostat de consentement TAA= thermostat air ambiati! DEI= déviateur été-hiver TAM= thermostat ambiarti à fixer sur le mur CVM= commutateur 3 vitesses à fixer sur le mur CEM= Commandes remotés Eté / Hiver - Thermostat d'ambiance - Commutateur trois vitesses - Commande soupapes CEM/D= Été / Hiver commutation manuelle et automatique - Thermostat d'ambiance - Commande soupapes commutateur trois vitesses manuelle et automatique - Commande Rés. électrique DTSR= doublé thermostat de sécurité résistance électrique RES= résistance électrique IRE= interrupteur rés. électrique REL= relais résistance pour mod. 40-80 EVI= électrovanne «refroidissement» EV2= électrovanne «chauffage» L= tige N= neutre ±= terre e= conditionnement e= blanc (moteur commuti) I= rouge (min.) II= bleu (moy.) III= noir (max.) e= ialine - vert (terre) f= alvmentation --- = limite câblage interne	C3V= comutador 3 velocidades TDC= termostato de asenso TAA= termostato aire ambiente DEI= desviador verano - invierno TAM= termostato amb. murai CVM= comutador 3 vel. murai mandos a distancia CEM. Estate/Inverno - Termostato ambiente - Comutador de tres velocidades - Mando valvulas Mandos a distancia CEM-D. Verano/Invierno . comutacion manual y automatica - Termostato ambiente - Mando valvulas Comutador de tres velocidades manual y automatica - Mando Res. Electrica DTSR= doble termostato de seguridad resistencia eléctrica RES= resistencia eléctrica IRE= interruptor res. eléctrica REL= relè resistencia para mod. 40-80 EV1= electrovàlvula "refrigeración" EV2= electrovàlvula "calefacción" L= linea N= neutro ±= ticrra e= acondicionamiento e= bianco (común motor) I= rojo (min) II= azul (med) III= negro (max) e= amarillo - verde (tierra) f= alimcntación --- = limite cableado interior
SOLO PER GRANDEZZE 60-80 C= bianco (comune) I= blu (min) II= nero (med) III= marrone (max)	JUSTFOR THE 60-80 SIZES C= white (common) I= blue (min.) II= black(med.) III= brown (max.)	NUR FUR DIE GROSSEN 60-80 C= weiB (einfadi) I= blau (min) II= schwarz (med) III= brami (max)	SEULEMENTPOURLES MODELES 60-80 C= blanc (commun) I= bleu (min.) II= noir (moy.) III= marron (max.)	SOLO PARA DIM. 60-80 C= bianco (común) I= azul (min) II= negro (med) III= marron (max)
Air = sonda ambiente remota H2O = sonda acqua EV = Elettrovalvola raffrescamento - riscaldamento per impianto a 2 tubi EV1= Elettrovalvola raffrescamento per impianto a 4 tubi EV2 = Elettrovalvola riscaldamento per impianto a 4 tubi	Air = Remote air probe H2O = Water probe EV = Cooling and Heating solenoid (2 pipes system) EV1 = cooling solenoid (4 pipes system) EV2 = Heating solenoid (4 pipes system)	Air = Raumsonde H2O = Zustimmungssonde EV = Electroventil "Kühlung Heizung" EV1= Electroventil "Kühlung" EV2 = Electroventil "Heizung"	Air = Sonde environnement H2O = Sonde consentement EV = Electrovanne "Refroidissement Chauffage" EV1= Electrovanne "Refroidissement" EV2 = Electrovanne "Chauffage"	Air = Sonda ambiente H2O = Sonda asenso EV = Electrovalvula "Refrigeracion calefaccion" EV1= Electrovalvula "Refrigeracion" EV2 = Electrovalvula "Calefaccion"

INTERFACCIA DI POTENZA - POWER INTERFACE - LEISTUNGSANSCHLUSS - INTERFACE DE PUISSANCE - ESTERFAZ DE POTENCIA


Attenzione, Attention, Achtung, Attention, Atención:

Utilizzare sempre l'interfaccia di potenza per collegare più ventilconvettori ad un solo comando remoto. Always use the power interface to connect more fan coils to single remote control. Leistungsanschluss immer zu benutzen um mehrere Klimakonvektoren zu ein einzigen Fernbedienung zu verbinden. Il faut utiliser toujours l'interface de puissance pour commander plusieurs (jusqu'à 4) ventilo-convection avec un seule commande a distance. Utilizar siempre la interfaz de potencia para conectar varios fan coils a un solo mando a distancia.

Schema elettrico - Wiring diagram

Elektrischer Schaltplan - Schéma électrique

Esquema eléctrico



I ventilconvettori modello VT 10-20-30-40, sono dotati di variazione della ventilazione, mediante auto-trasformatore a 6 posizioni.

Le posizioni certificate EUROVENT sono:

VT10 - VT20 - VT30 - VT40

Mosettiera autotrasformatore (vedi fig.)

© - Min. (rosso)

© - Med. (blu)

© - Max. (nero)

The VT 10-20-30-40 version fan-coil heaters have a fan regulator using a 6 position auto-transformer.

The certified EUROVENT positions are:

VT10 - VT20 - VT30 - VT40

Auto-transformer terminal board (follow the pict.)

© - Min. (red)

© - Med. (blue)

© - Max. (black)

Die Gebläsekonvektormodelle VT 10-20-30-40 sind mit einer Lüftungsregelung durch Spartransformator mit 6 Stellungen ausgestattet.

Die von EUROVENT zertifizierten Positionen sind:

VT10 - VT20 - VT30 - VT40

Klemmleiste Spartransformator (siehe fig.)

© - Min. (rot)

© - Mitt. (blau)

© - Max. (schwarz)

Die Ventilo-convecteurs VT 10-20-30-40 sont pourvus de variation de la ventilation, grâce à l'autotransformateur à 6 positions.

Les positions certifiées sont les suivantes:

VT10 - YT20 - VT30 - VT40

Plaque à bornes autotransformateur (voir le fig.)

© - Min. (rouge)

© - May. (bleu)

© - Maxi (noir)

Los ventilconvectores modelo VT 10-20-30-40 están dotados de variación de la ventilación, mediante auto-transformador de 6 posiciones.

Las posiciones certificadas EUROVENT son:



VT10 - VT20 - VT30 - VT40

Tablero de bornes autotransformador (ver fig.)

© - Min. (rojo)

© - Med. (azul)

© - Max. (negro)




PORATA ARIA RIFERITA ALLE VARIE POSIZIONI DEI COLLEGAMENTI ALL'AUTOTRASFORMATORE (mc/h) - AIRFLOW REFERRED TO THE VARIOUS CONNECTION POSITIONS TO THE AUTO-TRANSFORMER (m³/h) - LUFTDURCHSATZ FÜR DIE VERSCHIEDENEN POSITIONEN DER ANSCHLÜSSE AN DEN SPARTRANSFORMATOR (m³/h) - DEBIT AIR SE RAPPORTANT AUX DIVERSES POSITIONS DES BRANCHEMENTS A L'AUTOTRANSFORMATEUR (mc/h) - CAUDAL DE AIRE REFERIDO A LAS VARIAS POSICIONES DE LAS CONEXIONES AL AUTOTRANSFORMADOR (m³/h)

AUTOTRASFORMATORE - AUTO-TRANSFORMER AUTO-TRANSFORMER AUTOTRANSFORMATEUR AUTOTRANSFORMADOR	Pos. 1	Pos. 2	Pos. 3	Pos. 4	Pos. 5	Pos. 6
Mod. VT 10	333	296	252 ^③	200 ^②	147 ^①	128
Mod. VT 20	388	348	304 ^③	254 ^②	194 ^①	184
Mod. VT 30	584	505	430 ^③	353 ^②	254 ^①	232
Mod. VT 40	716 ^③	570	490 ^②	423	300 ^①	283

1.0 START UP

Control that the cover and filter are correctly assembled and that the electric connections have been made in conformity with the enclosed diagrams. Turn the heater on and check the controls to ensure the fan-coil heater and accessories work properly.

- 1 - Summer-winter-off selection switch.
- 2 - Fan regulation.
- 3 - Room temperature regulation (VTP/AB versions).



AIR CONDITIONING

HEATING

2.0 REGULATION ACCESSORIES

Ensure that the accessories have been correctly assembled and that the electric connections have been made as given in the instructions included with the kit.

* **READ THE INSTRUCTION MANUAL CAREFULLY BEFORE MAKING ANY SETTINGS OR CARRYING OUT THE MAINTENANCE WORK.**

* **IF THE FAN-COIL HEATER IS DISASSEMBLED AND REASSEMBLED THE INSTRUCTION MANUAL MUST BE SCRUPULOUSLY FOLLOWED.**

* **PAY SPECIAL ATTENTION TO HOW THE HEATER IS USED WHERE "ATTENTION" OR "DANGER" ARE WRITTEN, TO AVOID DAMAGE TO THE HEATER, PEOPLE AND PROPERTY.**

* **TONON S.P.A. DECLINES ALL RESPONSIBILITY FOR DAMAGE CAUSED BY INCORRECT USE OF THE FAN-COIL HEATER AND BY FAILURE TO FOLLOW THE INSTRUCTIONS GIVEN IN THIS MANUAL.**

3.0 USING THE FAN-COIL HEATER

Ensure that the air-intake zone is free and there is nothing covering the delivery grid (do not use it to dry washing, or place anything on top of it) otherwise the heater will not work correctly.

4.0 MAINTENANCE

Correct periodic maintenance means safe top quality performance. Before beginning any sort of maintenance:

- Turn the power off to the fan-coil heater
- Ensure that the solenoid or holder do not allow water to circulate in the exchanger.
- Use protective gloves

Once a month or after heavy use, clean the filter using a vacuum cleaner or wash it with neutral detergent. If the filter is still not clean request a new one from our service centre. How to remove the filter (see the figure):

- Unscrew the fixing screws.
- Pull the filter downwards towards the floor (or the wall in horizontal versions).

Once a year or after a long time without being used, clean the battery with a compressed airjet and check that the condensation outlets are not blocked.

Do not pour water onto the heater. The electric motor does not require maintenance.

If the heater is not used and the outside temperature falls below 0°C, empty the exchanger by opening the screws below the bottom attachment and add mono ethylene glycol to the water to lower the

freezing temperature to the required level.

5.0 FAULT FINDING

FAULT	CAUSE	REMEDY
No air comes out	The motor does not turn The central thermostat does not close	Check the power supply Increase the intake water temperature
Little air comes out	Blocked filter or battery Airflow blocked	Clean the filter and battery Unblock the airflow
Poor heating/cooling	Air in the hydraulic circuit Little water in the circuit Intake water temperature low/high	Bleed the hydraulic circuit Check the boiler or cooler Check the boiler or cooler

* FOR ANY PROBLEMS THAT ARE NOT COVERED BY THE INSTRUCTION MANUAL, CONTACT THE TONON S.P.A. SERVICE CENTRE.

ATTENTION

In case of fire water must not be used - only powder or CO₂ extinguishers.


SPARE PARTS

Use only original spare parts.

WARRANTY

The warranty is valid for 3 years (except the electric parts which are covered for 1 year). The warranty is valid from the date the heater is installed. The warranty is no longer valid if repairs or alterations are made by unauthorised persons, or due to faults that are not caused by original faults of the components or its construction.

DO NOT COVER



CARATTERISTICHE TECNICHE VENTILCOVETTORE CA' D'ORO - TECHNICAL FEATURES OF CA' D'ORO FAN COIL HEATES - TECHNISCHE EIGENSCHAFTEN KLIMAKONVEKTOR CA' D'ORO - CARACTERISTIQUES TECHNIQUES VENTILO-CONVECTEUR CA' D'ORO - DATOS TECNICOS VENTILCONVECTOR CA' D'ORO

Modello - Type - Modell - Modèle - Modelo		10	20	30	40	50	60	70	80
Potenza termica - Heating capacity - Heizleistung - Puissance termique - Potencia calorica (1) E	W max	2910	3770	5250	8870	12100	14300	17100	19200
Acqua ingresso 70°C, ΔT 10K - Intake water temperature 70°C, ΔT 10K - Temp. Wasservorlauf 70°C, ΔT 10K - Temp. entrée eau 70°C, ΔT 10K - Temp. entrada agua 70°C, ΔT 10K	W med	2430	3260	4490	6540	9870	12100	15300	17100
	W min	1900	2640	3460	4330	8190	9870	13000	15300
Portata acqua max - Water flow - Wassermenge - Debit d'eau - Caudal agua	l/h	254	329	459	776	1056	1246	1498	1677
Perdite di carico acqua - Pressuredrop - Druckverlust - Perte de charge - Perdita de carga	Kpa	3.08	6.92	4.34	13.1	6.9	7.08	12.2	14.9
Potenza termica - Heating capacity - Heizleistung - Puissance termique - Potencia calorifica (2) E	W max	1690	2030	2930	5240	6590	7500	9860	10700
Acqua ingresso 50°C - Intake water temperature 50°C - Temp. Wasservorlauf 50°C - Temp. entrée eau 50°C - Temp. entrada agua 50°C	W med	1420	1770	2530	3880	5430	5880	8800	9580
	W min	1120	1470	1960	2600	4480	4840	7770	8550
Perdite di carico acqua - Pressuredrop - Druckverlust - Perte de charge - Perdita de carga	Kpa	2.47	5.04	4.59	12.3	6.02	8.9	15.4	19.4
Potenza termica IR - Heating capacity - Heizleistung - Puissance termique - Petencia calorifica (4) E									
Batteria di scambio aggiuntiva an un rango - Additional one rank exchange battery - Leiter Zusätzl. Austauscher Batterie d'échange additionnelle à un rang-1 - Battería di intercambio adjunta de un rango	W max	1420	1910	2700	4080	5580	6070	7440	8150
Zusätzl. Austauscher Batterie d'échange additionnelle à un rang-1 - Battería di intercambio adjunta de un rango	W med	1210	1680	2350	3210	4570	5580	6920	7440
Acqua ingresso 70°C, ΔT 10K - Intake water temperature 70°C, ΔT 10K - Temp. Wasservorlauf 70°C, ΔT 10K	W min	980	1390	1600	2260	3890	4570	6050	6920
Temp. entrée eau 70°C, ΔT 10K - Temp. entrada agua 70°C, ΔT 10K									
Portata acqua max - Water flow - Wassermenge - Debit d'eau - Caudal agua	l/h	124	167	236	357	476	530	651	713
Perdite di carico acqua - Pressuredrop - Druckverlust - Perte de charge - Perdita de carga E	Kpa	3.00	6.07	12.3	27.8	21	23.3	42.1	46.7
Potenza frigorifera totale - Total cooling capacity - Kühlleistung Total (3) E	W max	1110	1560	2200	4210	4690	5790	7940	8500
Puissance frigorifique totale - Potencia frigorifica total	W med	960	1380	1880	3240	3570	4030	7210	7710
	W min	780	1130	1470	2250	2910	3030	6650	7000
Potenza frigorifera sensibile - Sensible cooling capacity - Kühlleistung Sensibel (3) E	W max	960	1120	1820	3040	3870	4860	5950	6620
Puissance frigorifique sensible - Potencia frigorifica sensible	W med	810	1070	1520	2270	3080	3870	5340	5950
	W min	640	860	1160	1520	2390	3080	4570	5340
Portata acqua max - Water flow - Wassermenge - Debit d'eau - Caudal agua	l/h	191	268	378	723	797	996	1365	1440
Perdite di carico acqua - Pressuredrop - Druckverlust - Perte de charge - Perdita de carga E	Kpa	1.59	5.93	5.41	14.7	9.60	10.3	17.9	21.5
Portata aria - Air flow - Luftmenge - Debit d'air - Caudal aire	mc/h max	252	304	430	716	920	1130	1320	1520
	mc/h med	200	254	353	490	720	920	1150	1320
	mc/h min	147	194	254	300	573	720	946	1150
Pressione sonora - Sound pressure level - Geräuschpegel - Pression sonore - Nivel sonoro	dB (A) max	38.5	38.5	41.5	45.5	48.5	54.5	52.5	57.5
	dB (A) med	34.5	34.5	35.5	37.5	40.5	48.5	48.5	53.5
	dB (A) min	28.5	27.5	27.85	26.5	34.5	41.5	43.5	49.5
Potenza sonora - Sound output - Schalleistung - Puissance sonore - Potencia sonora E	dB (A) max	47	47	50	56	57	63	61	66
	dB (A) med	43	43	45	46	49	57	57	62
	dB (A) min	37	36	36	35	43	50	52	58
Alimentazione elettrica - Power supply - Stromversorgung - Alimentation électrique - Alimentacion eléctrica							230V/1/50 Hz		
Potenza max ventilatore - Max fan capacity - Max Ventilatorleistung E	W	49	32	65	90	108	143	172	217
Puissance maximale ventilateur - Potencia max ventilador									
Corrente max assorbita - Max absorbed current - Max aufgenommener Strom - Puissance maximum absorbée - Corriente max absorbida	A	0.21	0.14	0.28	0.39	0.47	0.63	0.75	0.94
Resistenza elettrica (a richiesta) - Heating element (on request) - Elektrischer Widerstand (auf Anfrage) - Résistance électrique (en option) - Resistencia eléctrica (bajo pedido)	W	750	1000	1500	2000	2500	2500	3000	3000
Contenuto acqua batteria 3R (di serire) - 3 row water content - Wasserinhalt Austauscher 3R (serie) - Contenance en eau batterie 3R - Contenido de agua de la batería 3R	1	0.6	0.9	1.3	1.9	2.8	2.8	3.6	3.6
Contenuto acqua batteria IR (supplementare) - 1 row water - Wasserinhalt Austauscher IR (optionelle) - Contenance en eau batterie IR - Contenido de agua de la batería IR	1	0.2	0.3	0.4	0.5	0.9	0.9	1.2	1.2
Peso - Weight - Gewicht - Poids - Peso	Kg	14	17	20	23	35	35	47	47

“E”: Prestazioni certificate

EUROVENT

(1) - Riscaldamento:

Temperatura ambiente 20°C - Temperatura ingresso acqua 70°C - ΔT acqua 10°C

(2) - Riscaldamento “E”:

Temperatura ambiente 20°C - Temperatura ingresso acqua 50°C - Portata acqua come in raffreddamento alla vel. Max.

(3) - Raffreddamento:

Temperatura aria esterna 27°C b.s. - 19°C b.u.

Temperatura acqua ingresso 7°C - Uscita 12°C

(4) - Valori riferiti alla batteria aggiuntiva “IR” per impianti a “4 Tubi”, tutti gli altri valori sono riferiti alla versione base con batteria “3R” per impianti a “2 Tubi”

“E”: EUROVENT

Performance certificate

(1) - Heating: room

temperature 20°C, untake water temperature 70°C. ΔT water 10°C

(2) - Heating (E): room temp. 20°C, intake water temp. 50°C, water flow the same as cooling, all max. speed.

(3) - Cooling: room temp. 27°C dry bulb. 19°C damp bulb. water Temp. intake 7°C - outlet 12°C.

(4) - The values refer to the extra “IR” battery for the “4 tube” systems, all the other values refer to the basic version whit the “3R” battery for “2 tube” systems.

“E”: zertifizierte Leistungen

EUROVENT

(1) - Heizung:

Raumtemp. 20°C - Temp. Wasservorlauf 70°C - ΔT Wasser 10°C

(2) - Heizung “E”: Raumtemp. 20°C - Temp. Wasservorlauf 50°C - Wasserdurchfluss wie beim Kühlen auf max. 2 Geschw.

(3) - Kühlung: Temp. Raumluft 27°C mit feuchter Thermometerkugel, 19°C mit trocknen Thermometerkugel, Wassertemp. Vorlauf 7°C - Ablauf 12°C

(4) - Die Werte beziehen sich auf den Zusatzaustauscher “IR” für “4-Leiter-Systeme”, alle anderen Werte beziehen sich auf die Basisversion mit Austauscher “3R” für “2-Leiter-Systeme”

“E”: Prestations certifiées

EUROVENT

(1) - Réchauffement: temp. ambiante 20°C, temp. entrée eau 70°C. ΔT eau 10°C

(2) - Réchauffement (E): temp. ambiante 20°C, temp. entrée eau 50°C, débit eau comme dans la phase de refroidissement vitesse max.

(3) - Refroidissement: temp. air ambiant 27°C bulbe sec. 19°C bulbe humide, temp. eau entrée 7°C - sortie 12°C

(4) - Valeurs référencées à la batteriesupplémentaire “IR” pour installations à “4 TUBES”, toutes les autres valeurs se réfèrent à la version base batterie “3R” pour installation à “2 TUBES”.

“E”: Rendimientos certificados EUROVENT


(1) - Calefacción: Temp. ambiente 20°C - Temp. entrada agua 70°C - ΔT agua 10°C

(2) - Calefacción “E”: Temp. ambiente 20°C - Temp. entrada agua 50°C - Caudal agua corno el refrigeración la vel. max.

(3) - Refrigeración: Temp. aire ambiente 27°C b.s. - 19°C b.h., Temp. agua entrada 7°C - salida 12°C

(4) - Valores referidos a la batería adicional “IR” para instalaciones a “4 TUBOS”, todos los otros valores se refieren a la versión base con batería “3R” para instalaciones a “2 TUBOS”

UNITA BASE - BASIC UNIT - BASISEINHEIT - UNITE BASE - UNIDAD BASE



COMPONENTI PRINCIPAL	MAIN COMPONENTS	HAUPTBESTANDTEILE	COMPOSANTES PRINCIPALES	COMPONENTES PRINCIPALES
1 Batteria di scambio	1 Exchange battery	1 Warmeaustauscher	1 Batterie d'échange	1 Bateria de intercambio
2 Batteria supplementare IR (a richiesta)	2 Single rara, additional battery (on request)	2 Zusatzaustauscher IR (auf Anfrage)	2 Batterie supplémentaire R (en option)	2 Bateria suplementaria IR (a petición)
3 Struttura portante	3 Bearing structure	3 Tragende Struktur	3 structure portante	3 Estructura portante
4 Gruppo ventilante	4 Fan unii	4 Gebläse	4 Groupe de ventilation	4 Grupo ventilador
5 Pannello comandi	5 Control panel	5 Bedienblende	5 Panneau de commande	5 Panel de mandos
6 Mobile di copertura	6 Cover	6 Abdeckgehäuse	6 Meublé de couverture	6 Mueble de copertura
7 Sezione filtrante	7 Filterunit	7 Filter	7 Groupe defiltration	7 Sección filtrante
8 Sportello sx	8 Uhflap	8 Klappe links	8 Porte gche	8 Puerta izquierda
9 Sportello dx	9 R/hflap	9 Klappe rechts	9 Porte dte	9 Puerta derecha
10 Griglia diffusore	10 Diffuser grid	10 Verteilergitter	10 Grille diffuseur	10 Rejilla de difusión
11 Vaschetta esterna (a richie- sta)	11 Outside tray (on request)	11 AuBere Wanne (auf Anfrage)	11 Cuve externe (en option)	11 Bandeja externa (a petición)
12 Termostato di consenso	12 Consent thermostat	12 Freigabe-Thermostat	12 Thermostat de consentement	12 Termostato de asenso
13 Targhetta caratteristiche	13 Technical feature plaque	13 Typenschild	13 Plaquette caractéristiques	13 Placa de características